



Boost control wiring.

Without control (connector disconnected) = base pressure = minimum boost pressure

SPECIAL TUNING HARINEN OY  
HELMUNTIE 83  
37600 VALKEAKOSKI  
[www.hestec.fi](http://www.hestec.fi)

HESTEC  
HARINEN 32  
kytkentäkaaviot